


SCHEME EXPLODATE



PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
1	Breathing cap	9	Screw	17	Bearing2	25	Piston	33	Valve packing	41	Tank	49	Pressure gauge	57	Screw
2	Screw	10	Crank case	18	Motor frame	26	Scraper ring	34	Valve plate	42	Aluminum pipe	50	Connector	58	Water drain valve
3	Cover	11	Bearing1	19	Screw	27	Compression ring	35	Valve seat	43	Connector	51	Air cock	59	Wheel
4	Oil glass	12	Seal	20	Fan	28	Cylinder packing	36	Valve packing	44	Screw	52	Regulator kits	60	Pin(wheel)
5	O ring	13	Screw	21	Snap ring1	29	Cylinder	37	Elbow assembly	45	Electrical wire	53	Pressure gauge		
6	Cover"O"ring	14	Reset	22	Motor cover	30	Screw	38	Screw	46	Electrical plug	54	Exhaust hose		
7	Connecting rod	15	Condenser	23	Snap ring2	31	Bolts	39	Cylinder head	47	Safety valve	55	Check valve kits		Exploded View
8	Crank shaft	16	Motor	24	Piston pin	32	Valve packing1	40	Filter element	48	Pressure switch	56	Rubber feet		

